





Note: The location of the Wake setting may vary depending on the BIOS version. Please configure it according to the corresponding version.

- 1 When the computer starts up, press the [DEL] key on the keyboard to enter the BIOS interface.
- 2 Use the left and right arrow keys on the keyboard to navigate to the [Advanced] page, select [ACPI Settings], and press the [Enter] key to enter the settings page.
- 3 Set [Wake system with Fixed Time] to [Enabled].
- 4 Set [RTC Alarm Date (Days)] to [Everyday] and use the keyboard's + and - keys to adjust the time (hour, minute, and second) for the wake-up.
- 5 Finally, press the [F10] key on the keyboard to save the settings and exit. The system will reboot and enter Windows.



Note: The location of the Wake setting may vary depending on the BIOS version. Please configure it according to the corresponding version.

- 1 When the computer starts up, press the [DEL] key on the keyboard to enter the BIOS interface.
- 2 Use the left and right arrow keys on the keyboard to navigate to the [Boot] page, select [S5 RTC Wake Settings], and press the [Enter] key to enter the settings page.
- 3 Set [Wake On RTC] to [Enabled].
- 4 Set [Wake up day] to [Everyday] and use the keyboard's + and - keys to adjust the time (hour, minute, and second) for the wake-up.
- 5 Finally, press the [F10] key on the keyboard to save the settings and exit. The system will reboot and enter Windows.



Note: The location of the Wake setting may vary depending on the BIOS version. Please configure it according to the corresponding version.

- 1 When the computer starts up, press the [DEL] key on the keyboard to enter the BIOS interface.
- 2 Use the left and right arrow keys on the keyboard to navigate to the [Advanced] page, select [ACPI Settings], and press the [Enter] key to enter the settings page.
- 3 Set [Resume On RTC Alarm] to [Enabled].
- 4 Set [RTC Alarm Date(Days)] to [Everyday] and use the keyboard's + and - keys to adjust the time (hour, minute, and second) for the wake-up.
- 5 Finally, press the [F10] key on the keyboard to save the settings and exit. The system will reboot and enter Windows.

